



Part Number	Thread	A	B	C	D
R20-XLTS	1/4-20	3.42"	0.75"	0.375"	3"
R20-XLTS-RT (Rubber Tipped)	1/4-20	3.42"	0.75"	0.375"	3"
R8-XLTS	M8	87 mm	19 mm	9.5 mm	76 mm
R20-XLTS-RT (Rubber Tipped)	M8	87 mm	19 mm	9.5 mm	76 mm
R6-XLTS	M6	87 mm	19 mm	9.5 mm	76 mm
R6-XLTS-RT (Rubber Tipped)	M6	87 mm	19 mm	9.5 mm	76 mm

X-Large Tension Spring



Part Number	Thread	A	B	C	D
R20-XLTSP	1/4-20	3.625"	0.75"	0.275"	3"
R8-XLTSP	M8	92 mm	19 mm	7 mm	76 mm
R6-XLTSP	M6	92 mm	19 mm	7 mm	76 mm

X-Large Tension Spring with Plunger



Part Number	Thread	A	B
R20-WTS-125-1	1/4-20	1.25"	1"
R20-WTS-2-2	1/4-20	2"	2"
R20-WTS-125-2	1/4-20	1.25"	2"
R20-WTS-2-1	1/4-20	2"	1"
R20-WTS-125-1-RT (Rubber Tipped)	1/4-20	1.25"	1"
R20-WTS-2-2-RT (Rubber Tipped)	1/4-20	2"	2"
R20-WTS-125-2-RT (Rubber Tipped)	1/4-20	1.25"	2"
R20-WTS-2-1-RT (Rubber Tipped)	1/4-20	2"	1"
R6-WTS-32-25	M6	32 mm	25 mm
R6-WTS-50-50	M6	50 mm	50 mm
R6-WTS-32-50	M6	32 mm	50 mm
R6-WTS-50-25	M6	50 mm	25 mm
R6-WTS-32-25-RT (Rubber Tipped)	M6	32 mm	25 mm
R6-WTS-50-50-RT (Rubber Tipped)	M6	50 mm	50 mm
R6-WTS-32-50-RT (Rubber Tipped)	M6	32 mm	50 mm
R6-WTS-50-25-RT (Rubber Tipped)	M6	50 mm	25 mm
R4-WTS-32-25	M4	32 mm	25 mm
R4-WTS-50-50	M4	50 mm	50 mm
R4-WTS-50-25	M4	50 mm	25 mm
R4-WTS-32-50	M4	32 mm	50 mm
R4-WTS-32-25-RT (Rubber Tipped)	M4	32 mm	25 mm
R4-WTS-50-50-RT (Rubber Tipped)	M4	50 mm	50 mm
R4-WTS-50-25-RT (Rubber Tipped)	M4	50 mm	25 mm
R4-WTS-32-50-RT (Rubber Tipped)	M4	32 mm	50 mm

Wire Tension Springs

